

Fabric Insert Installation

TOOLS NEEDED: None

WHAT'S IN THE BOX: (5) fabric inserts

STEP 1: Begin by inserting the **RED**-edged, rubber strip (along the edge of the fabric) into the groove at the four corners of the frame. Make sure the rubber strip edges come together for a smooth corner making sure the fabric corner is tucked in.

STEP 2: Insert the middle of each of the four sides of the fabric into the grooves and work your way out to the corners on each side. Be careful not to over-stretch the fabric when placing it into the grooves of the frame. Over-stretching the fabric will prevent the graphic from fitting correctly into the frame.

NOTE: The graphic fabric is designed to stretch to a taught, smooth fit. Your fabric will first appear to be too short to fit into the **BOTTOM** frame groove. With one hand, pull the fabric just beyond the edge of the frame. With your other hand, gently insert the fabric edge into the groove.

STEP 3: After you fit the last portion of the graphic fabric into the end of the groove, slide your thumb back along the edge of the frame to smooth away any bumps that may have resulted. If wrinkles occur, take out sections and repeat Step 2 until you achieve a smooth finish.

