




# Certified Service Lettering for Service Advisor Podium Instruction Sheet

## Installation

1. Place the “Certified Service” letters on the front of your service desk. Align the left edge and bottom as shown below. Tape in position.
2. Carefully lift the bottom edge and peel the inside clear liner from the masking paper and white letters.
3. Once the clear liner is removed from the letters and top masking sheet, allow letters and masking sheet to fall back into the original taped position from step 1.
4. Using your fingertips on the masking sheet, carefully burnish each letter, transferring the letter to the desk.
5. Once all letters are adhered to the desk, slowly remove the top masking paper, starting from the top left corner, leaving the white lettering in place on the desk. Pull the masking paper at a 30-degree angle down and to the right.



**If you have any questions, please call 1-800-766-5660.**